

Installation Guidelines for Detectable Warning[®] Pavers Cast-In-Place

1 Concrete: Maintain a 4 - 7 slump range, pour and float the concrete.



2 Placing Pavers:

Trowel off a section of concrete in the area to receive Detectable Warning[®] Pavers. Do not remove full depth as pavers will be malletted into place at final grade. Place the paver on the curb ramp, 6" to 8" from the curb line or face of curb. Keep paver domes aligned and equally spaced.



After pavers are laid in place, use trowel to level concrete. Be cautious not to push concrete over the edge of the paver onto the surface, as it will stain. Trowel the edge smooth.



3 Leveling:

Tamp the Detectable Warning[®] Pavers in a grid pattern across the top face, embedding the pavers into the concrete using a white or non-marring mallet. Be cautious not to push concrete over the paver edge and onto the surface.



Continue to tamp with the mallet until the paver is level with the finished surface of the concrete. Truncated domes must be $\frac{3}{8}$ " above finished level in order to meet ADA approval.



4 Finishing:

Create an edge around the perimeter of the pavers using a $\frac{3}{8}$ " radius-edging tool. Float the concrete around the perimeter of the pavers using a steel trowel.



Apply a broom finish to the curb ramp.

Please Note: These installation guidelines are recommendations only. Installation techniques may vary depending on geographic location and municipal requirements. Contact your local authority for specific installation instructions. An industry professional should be consulted to develop a specification for the individual project in accordance with the municipal requirements.

Instrucciones para la Instalación de Baldosas de Aviso (Detectable Warning Paver) sobre hormigón fresco.

1.- Hormigón Manteniendo un 4-7 de rigidez (slump) vaciar y allanar el hormigón



2.- Colocación de las Baldosas de Aviso (DWP)

Allane una sección de hormigón para sentar las Baldosas Dejar ligeramente alta la base ya que las Baldosas se golpearan con un martillo para fijarlas y nivelarlas Coloque la Baldosa en la rampa de acera de 6" a 8" desde la linea o frente de la acera.Mantenga las cúpulas alineada

Después de colocar las Baldosas nivele y allane el hormigón hasta el borde de las Baldosas cuidando de manchar la superficie

3.- Nivelado

Golpear las Baldosas con un martillo que no manche para nivelarlas y fijarlas Si el hormigón manchara la superficie de la Baldosas, limpiarla inmediatamente con agua limpia



Las cúpulas deberán quedar a 3/8" por encima de la superficie final de la acera según las normas de ADA

4.- Acabado

Cear un borde alrededor de las Baldosas con una llana con borde radial de 3/8"

Allanar el hormigón alrededor de las Baldosas (DWP) y barrerlo con una escoba rígida. Limpiar toda el area de trabajo y asegurarse de que las Baldosas están limpias.

Advertencia.- Estas instrucciones son sólo recomendaciones. La instalación de las Baldosas de Aviso (DWP) puede variar dependiendo de la zona geográfica o normas de municipios y condados. Deben contactarse las autoridades locales ,ya que pueden tener instrucciones específicas para la instalación